


Dashboard Camera

**THINKWARE**

# Wi-Fi Connection For iOS Devices



# Connecting a smartphone to the dash cam


If you connect your smartphone to the dash cam via Wi-Fi, you can view and manage recorded videos and configure various dash cam features with your smartphone.




- iOS 8.0 or higher is required to use the THINKWARE CLOUD application.
- Default Wi-Fi password is **123456789**.

1  On your iOS device, open the App Store, download and install the **THINKWARE CLOUD** app.

2  Run the **THINKWARE CLOUD** app.



Tap **Dash cam connection is required** at the bottom of the screen.



On the Wi-Fi connection section, tap **Connect**.


5 On the product, press the Wi-Fi (📶) button.




From the **THINKWARE CLOUD** app, tap **Next**.



Tap **Wi-Fi Settings**. It will take you to the Wi-Fi settings.




From the network list on your iOS device, select the Wi-Fi network starting with **"Thinkware."**




Enter **"123456789"** in the password field and tap **Join**.

10



Return to the **THINKWARE CLOUD** app and check that **“Dash cam is connected via Wi-Fi”** is displayed at the bottom of the screen. The product is now connected to your iOS device via Wi-Fi.

### Resetting Wi-Fi on the F800 and F800PRO models




Press and hold the voice recording (🎤) and manual recording (□) buttons simultaneously until you hear beeps.

The Wi-Fi has finished resetting when you hear the dash cam say, “**System will restart.**”



Make sure you back up your recorded videos on the dash cam before resetting Wi-Fi. When you reset Wi-Fi, all settings and recorded videos stored on the dash cam will be deleted.

### Resetting Wi-Fi on the F200 and FA200 models



Press and hold the **REC** and Wi-Fi (📶) buttons simultaneously until you hear beeps.

The Wi-Fi has finished resetting when you hear the dash cam say, “**System will restart.**”



Make sure you back up your recorded videos on the dash cam before resetting Wi-Fi. When you reset Wi-Fi, all settings and recorded videos stored on the dash cam will be deleted.

<http://www.thinkware.com>